



Instruction manual

P 29.2 Differential Pressure Transmitter



Zur Vermeidung von Explosions-
gefahr vor Inbetriebnahme
geeignete Vorspülzeit einhalten

To avoid risk of explosion
flush for an adequate amount
of time prior to operation

Menu

0

◀ ▶

↑ ↓

halstrup
walcher

halstrup-walcher GmbH
Stegener Straße 10-12
79199 Kirchzarten

Phone +49 7661 39 63-0
info@halstrup-walcher.de
www.halstrup-walcher.de

© 2026

Original Instruction manual

The copyright to this instruction manual remains with the manufacturer. It contains technical data, instructions and drawings for the function and handling of the device. It may not be reproduced in whole or in part or made available to third parties.

Table of contents

1 Safety instructions	5
1.1 Purpose of this operating instructions.....	5
1.2 Target group.....	6
1.3 Symbol explanation	6
1.4 Security	6
1.5 Intended use.....	7
1.6 Inappropriate use.....	8
1.7 Limitation of liability	9
1.8 Assembly, connection and commissioning	9
1.9 Faults, maintenance	10
1.10 Repair	10
1.11 Storing and transporting equipment	10
1.12 Disposal Notice	11
1.13 Product labelling.....	12
2 Operation and Handling	13
2.1 Commissioning.....	13
2.2 Decommissioning, recommissioning	14
2.3 Leak testing	14
2.4 Transport	15
3 Assembly	16
3.1 Mount/Unmount on a DIN rail	16
3.2 Wall installation	17
3.3 Torque values during device assembly.....	17
4 Device Description	18
4.1 Description	18
4.2 Frontal view.....	18
4.3 Status LED	19
4.4 Configuration interface	19
4.5 Zeroing	19
4.5.1 Zeroing Interval	20
4.5.2 External Zeroing	20
4.6 Overpressure protection.....	20
5 Electrical connection	21
5.1 Power consumption	21
5.2 Preparing supply voltage through cable glands.....	21
5.2.1 Selection of the cable cross-section.....	22
5.2.2 Connection of the supply voltage	23
5.2.3 Connection of input and output signals	23
5.2.4 Connection of the semiconductor switches (option).....	24
5.3 Supply voltage through connection plug.....	25
5.4 Starting conditions of the measuring system.....	25

6	Functionality	26
6.1	User interface	26
6.2	Login.....	27
6.3	Alerts	27
6.4	Device Info	29
6.5	Application	29
6.5.1	Mode	29
6.5.2	Pressure measurement.....	30
6.5.3	Characteristic curve calculation.....	31
6.6	Outputs	33
6.6.1	Analog Outputs.....	33
6.6.2	Switching Outputs (Relays).....	35
6.7	Display settings (optional).....	37
6.8	Device settings	38
6.9	Firmware update.....	39
6.10	Display (option).....	39
6.11	Menu Tree	41
7	Specifications.....	44
8	Notes	45

1 Safety instructions

This section provides an overview of all important safety aspects for optimal protection of personnel as well as for safe and trouble-free operation.

1.1 Purpose of this operating instructions

This operating manual explains the function and handling of the P 29.2 differential pressure transmitter. The operating instructions are part of the product and must be kept for the entire life of the device.

Any person assigned to carry out work on or with the equipment must have read and understood the operating instructions before starting work on the equipment. This also applies if the person in question has already worked with such or similar equipment or has been trained by the manufacturer.

These devices can pose a risk to persons and property due to improper use and incorrect operation. Therefore, every person who is entrusted with the handling of the equipment must be instructed and know the dangers. The operating instructions and in particular the safety instructions given therein must be carefully observed.

Be sure to contact the manufacturer if you don't understand any parts of it.



WARNING!

In particular, the instructions for commissioning in systems with flammable gases must be read and observed.

Be sure to contact the manufacturer if you don't understand any parts of it.

Handle these operating instructions carefully:

- It must be kept handy during the life of the equipment.
- It must be passed on to subsequent staff.
- Supplements issued by the manufacturer must be inserted.

The manufacturer reserves the right to further develop this device type without documenting this in each individual case. The manufacturer will be happy to provide you with information on the current status of these operating instructions.

You can find more technical information about your product at the following link:

<https://www.halstrup-walcher.de/en/downloads/>

1.2 Target group

This operating manual is intended for qualified electricians who are authorised to install, electrically connect, commission and label devices and systems in accordance with safety standards, as well as for the operator and manufacturer of the system.

The personnel must be provided with all applicable accident prevention and safety regulations that arise during the commissioning or installation of the system.

It must be ensured that personnel are familiar with all applicable accident prevention and safety regulations.

1.3 Symbol explanation

The device has been designed and tested to ensure its safety. However, it may still be dangerous if used inappropriately. Precautions must be taken to prevent the device being used incorrectly by mistake.

The following warnings are used in this instruction manual:

 DANGER!	DANGER! Failure to comply with this safety notice will result in death or serious bodily injury.
 WARNING!	WARNING! Failure to comply with this safety advice may result in death or serious bodily injury.
 CAUTION!	CAUTION! Failure to comply with this safety advice may result in moderate or minor bodily injury.
NOTICE	NOTE: Failure to comply with this safety notice may result in property damage.

1.4 Security

When used in systems with natural gas, the entire pressure system must be flooded with the gas before the electrical supply is switched on. This creates a non-explosive atmosphere in the gas-carrying system of the device.

 WARNING!
Both pressure connections must remain always connected to the pressurized system.

The P 29.2 has been subjected to an ignition hazard assessment in accordance with DIN EN 1127-1:2019. Under normal operating conditions, there is no explosive atmosphere in the transmitter. It therefore does not receive an ATEX marking, as it does not fall within the scope of Directive 2014/34/EU.

1.5 Intended use



DANGER!

The device may only be mounted outside potentially explosive atmospheres.

The P 29.2 is used to measure differential pressure, volume flow, mass flow and flow velocity by means of a measuring orifice. In compliance with the rules on commissioning described in chapter **2 Operation and Handling**, its use in systems with natural gas is permitted.



WARNING!

The operator of the device is responsible for supplying a pure (oxygen-free) fuel gas atmosphere (natural gas). The manufacturer is not liable for damage resulting from improper or improper use.



WARNING!

Failure to comply with this safety advice may result in serious bodily injury and damage to property.

The operating requirements specified on the nameplate and in the chapter "Technical data", in particular the permissible supply voltage, must be complied with.

The device is not intended for outdoor use.

The operating requirements stated on the nameplate and in the data sheet, in particular the permissible supply voltage, must be complied with.

The appliance must only be handled in accordance with these operating instructions. Changes to the device are not permitted.

The manufacturer is not liable for damage resulting from improper or improper use. In this case, the warranty claims also expire. Repair measures may only be carried out by the manufacturer.

NOTICE

The device is used as intended if all instructions and information in these operating instructions are observed.

- Only operate the device in perfect technical condition.
- Observe the relevant regulations for the prevention of accidents (e.g. accident prevention regulations).
- Store and transport the product in its original packaging, reuse plug caps if necessary.

1.6 Inappropriate use

The use of the differential pressure transmitter outside the operating conditions described in the documentation and the technical data and specifications specified in the documentation is considered "not in accordance with its intended purpose".

The P 29.2 is designed to operate as intended under normal environmental conditions (in accordance with EN/IEC/UL 61010-1), with the exception of an extended temperature range:

- Operation in the interior of buildings
- Operation at altitudes up to 2000 m above sea level
- Ambient temperatures deviating from the standard: 10°C to 50°C
- Maximum relative humidity 80% at temperatures up to 31°C, decreasing linearly to 50% relative humidity at 40°C
- Supply voltage fluctuations up to \pm 10% of the nominal voltage
- Transient overvoltages up to the values of overvoltage category II.



WARNING!

Any use of the device beyond its intended use and/or in any other way can lead to dangerous situations

- Submerged operation is not permitted.
- Exceeding the requirements set out in **7 Specifications** may result in personal injury or property damage.
- The device should be installed in such a way that it is not mounted unprotected or in an exposed position to avoid accidental damage – for example by passenger traffic or transport operations.

1.7 Limitation of liability

The appliance must only be handled in accordance with these operating instructions. All information and information in this operating manual has been compiled taking into account the applicable standards and regulations, the state of the art and our many years of experience and knowledge.

The manufacturer assumes no liability arising from improper or improper use. In this case, the warranty claims also expire:

- non-observance of the operating instructions
- improper use
- improper installation
- non-intended use
- Use by untrained personnel
- Changes to the device
- Technical modifications
- Unauthorized modifications

The user is responsible for carrying out the commissioning in accordance with the safety regulations of the applicable standards and all other relevant state or local regulations regarding conductor dimensioning and protection, grounding, disconnectors, overcurrent protection, etc. The person who carried out the assembly or installation is liable for damage that occurs during assembly or connection.

1.8 Assembly, connection and commissioning

The installation and electrical connection of the device may only be carried out by qualified personnel. It must be instructed and commissioned by the operator of the facility. This is especially true for systems that work with natural gas. The special commissioning rules (see chapter **2.1 Commissioning**) must be observed here.

The following ignition hazards must be taken into account during installation:

- "Hot gases" The gas temperature of the natural gas must be within the permissible ambient temperatures of the appliance. If necessary, ensure sufficient cooling or heating of the gas or mount the device in a place where the natural gas has reached the ambient temperature of the device.
- "Self-ignition of dusts" The device must not be mounted in a dust explosion zone (zones 20, 21 or 22). If heavy dust build-up is expected on the device, please ensure regular cleaning with a damp cloth.
- "Lightning strike" Do not mount the device and its supply lines outdoors. Ensure sufficient surge protection of the supply voltage.

The P 29.2 pressure transmitter is a precision measuring device and should be handled with care despite its robustness. Installation in the immediate vicinity of heat and radiation sources should be avoided. It is advisable to attach the device to a vibration-free wall in a vertical installation position (hose connections for pressure (+) and vacuum (-) point downwards).

Only instructed persons commissioned by the plant operator are allowed to operate the device.

**CAUTION!**

Do not perform a functional test with compressed or breathing air. Devices with low measuring ranges will otherwise be damaged.

The pressure connections may only be connected and disconnected when switched off. Protect the device from sunlight, otherwise measurement errors will occur. Special safety instructions are given in the individual chapters.

The appliance must only be opened in clean and dry environments.

1.9 Faults, maintenance

Faults or damage to the appliance must be reported immediately to the specialist personnel responsible for the electrical connection.

The device must be taken out of operation by the responsible specialist staff until the fault has been rectified and secured against accidental use.

The device does not require any maintenance.

The appliance may only be cleaned from the outside with a damp cloth.

1.10 Repair

Replace the fuse

To avoid unnecessary service and associated equipment failure, you can replace the fuse. The fuse can be removed by hand.

See figure in chapter **5 Electrical connection**.

During the following steps, the device must be disconnected from the power supply.

To replace the fuse, follow these steps:

1. Make sure that the device is de-energized.
2. Pull the fuse upwards.
3. Then plug the new fuse back in accordingly.

Use only the following backup:

Miniature fuse TR5, inert, nominal current: 315mA, nominal voltage 250V, polarity is not to be considered.

Repair measures may only be carried out by the manufacturer.

1.11 Storing and transporting equipment

The P 29.2 differential pressure transmitter should always be stored in its original packaging and made available for assembly in its original packaging.

1.12 Disposal Notice

The electronic components of the device contain environmentally harmful substances and are also recyclable material carriers. The device must therefore be recycled after its final decommissioning. The environmental guidelines of the respective country must be observed for this purpose.

halstrup-walcher GmbH is registered under WEEE Reg. No. 14807488 and offers business customers the option of returning their old B2B electrical and electronic equipment purchased from halstrup-walcher GmbH for a fee to ensure reuse, recycling, and environmentally friendly disposal. To arrange the return of an old B2B device, please use the WEEE return form available on our homepage.

1.13 Product labelling

The warning icons included in this guide are for general safety and may not apply to this device without exception. Relevant symbols and notes are only valid in connection with the actual device configuration and the intended purpose.

Symbol	Meaning
	Reference to further documentation Read the operating instructions and safety instructions before transport, installation, or commissioning
	Warning of dangerous electrical voltage Before working on the product, check whether all power connections are de-energized!
	Disposal of batteries, electrical and electronic equipment According to international regulations, batteries, rechargeable batteries and electrical and electronic equipment may not be disposed of with household waste. The owner is legally obliged to dispose of these devices properly at the end of their service life. WEEE: This symbol on the product, its packaging or in this document indicates that a product is subject to the said regulations.
	CE marking CE stands for "Conformité Européenne". The CE marking expresses the conformity of a product with the relevant EC directives.
	Risk of explosion The utmost caution is required when handling flammable gases! In combination with atmospheric oxygen, highly explosive mixtures can form.
	Class II Equipment with protection class II has reinforced or double insulation between active and touchable parts.
	Class III Equipment is designed to be supplied from a safety extra-low voltage (SELV) or a protective extra-low voltage (PELV) power source.

2 Operation and Handling



WARNING - RISK OF EXPLOSION!

Beware of the risk of explosion! Observe the appropriate pre-rinsing time before commissioning!

2.1 Commissioning



WARNING!

Read and follow the following commissioning instructions carefully. Failure to observe this can lead to the explosion of the device and thus to personal injury.

The device may only be installed and operated by persons who are trained in the handling of equipment in hazardous areas.

During the following steps, the device must be disconnected from the power supply.

- Device to the system (see chapter **3 Assembly**) – not yet connect to the gas pipe.
Make sure that the installation is only carried out outside hazardous areas.
- All electrical connection cables (de-energized) in the device install
(see chapter **5 Electrical connection**)
- Test function
 - Check the flow between the positive and negative pressure connections
(check the pre-flush function)
 - Apply supply voltage
 - Briefly check pressure measurement function
 - Turn off the power supply again
- Tightening cable glands
- Unused cable glands must be sealed
- Close the case
- Before connecting the device to the gas pipes, the two pressure supply lines to the P 29.2 should be flooded with gas, otherwise the time that the device itself has to be flooded will be extended. Suitable equipment must be installed for this purpose.
- **Rinsing process**
 - Block gas supply lines
 - Connect both pressure ports
 - **Tighten and check the terminals on the gas supply lines**
 - Release gas supply lines
 - **Flood the device with gas for at least 6 minutes when switched off, for this purpose there must be a differential pressure at pressure connections. Note the maximum system pressure -> under point 7 Specifications**
- Only then may the power supply be switched on again

The purpose of this commissioning regulation is to flush the oxygen necessary for combustion out of the device, so that only a pure gas atmosphere is present in the device. This gas atmosphere cannot ignite because there is no oxygen. If the appliance is disconnected from the gas supply line, even temporarily, this commissioning process must be repeated. Consequently, both pressure connections must be connected to the pressurized system during operation.

**WARNING!**

Without compliance with this commissioning regulation, the device may not be operated in systems with natural gas.

2.2 Decommissioning, recommissioning

**WARNING!**

Maintenance or repair work may only be carried out by trained specialists and on behalf of the plant operator.

The following steps must be carried out before the maintenance work begins.

- Disconnect the device from the power supply
- Blocking the gas supply line
- Disconnect gas supply lines
- Open Device
- Loosen electrical connections
- Dismantle the device
- Flush the appliance
for at least 2 minutes when switched off on one side of the positive or negative pressure connection with air ($P = 100\dots 1000\text{mbar}$) so that the gas is flushed out. Use only air to flush the appliance.
- New device after which is described in chapter **3 Assembly** procedure described above and put it into operation

2.3 Leak testing

The user can perform regular leak tests as a simple pressure test if required.

For the leak test, shut off the two pressure supply lines to the P 29.2 and note the initial pressure (display or output signal). Note the differential pressure for 1 minute. The differential pressure must not drop over this period.

Please note that strong temperature fluctuations in the confined volume can also lead to changes in pressure.

2.4 Transport



WARNING!


In appliances that have been operated with natural gas, there may still be gas residues in the appliance. These must be rinsed out before packing.

To ensure that there are no more gas residues in the device, once the device has been installed in a system that works with natural gas, it must be connected to the positive or negative pressure connection with air ($P = 100\ldots 1000\text{mbar}$) for at least 2 minutes so that the gas is flushed out. This is especially true if several devices are to be shipped in the same box.

3 Assembly

You can mount the device on a DIN rail or screw it to a wall.

Install the device with pressure connections facing downwards so that any condensation that may occur in the hoses does not run into the sensor.



Installation in the immediate vicinity of heat and radiation sources (e.g. radiators, solar radiation...) should be avoided, as this can lead to measurement errors.


You can also use the STP file, which you can download from our website, for planning purposes: <https://www.halstrup-walcher.de/en/downloads/>

3.1 Mount/Unmount on a DIN rail

The housing is prepared for DIN rail mounting.


1. Place the housing in the desired position with the top recess on the DIN rail.
2. Snap it into place by pressing down on the device.

The device is now mounted.



NOTICE

To unmount the device, pull the red tab down using a screwdriver.




3.2 Wall installation

You can attach the device to the wall with 2 screws.

1. Prepare the drill holes.
2. Place the device against the wall.
3. First, screw the right screw into the wall and do not tighten it all the way yet.
4. Screw in the left screw.
5. Screw both screws into the wall, do not tighten them all the way yet.
6. Use the slotted holes for alignment/adjustment.
7. Then tighten all the screws tightly.

The device is now installed on the wall.

The following illustration shows the rear view of the device with drilling distances and mounting points.



3.3 Torque values during device assembly

The following torque values must be observed when installing the P 29.2:

Designation	Tightening torque in Nm
Cover screw	0,75
Cable gland	0,75
M12-plug	0,6
Clamping fitting	Depending on the materials used, it is recommended to hold the wrench in place with a second spanner

4 Device Description

4.1 Description

The functions of the P 29.2 at a glance:


- Measurement of pressure differences
- Derivation of volume flow, mass flow, and flow velocity
- Two analogue outputs and two freely configurable switching outputs
- USB-C configuration port for PC connection
- Real-time data reading and configuration with "Start-Up Tool P 2x.2"

The P 29.2 is a high-precision measuring device for detecting pressure differences in technical systems. Based on this pressure data, it automatically calculates volume flow, mass flow and flow velocity.

The device can be integrated into control and automation systems via the two analogue and freely configurable switching outputs. With the USB-C port, you can connect the P 29.2 to a PC and use the "Start-Up Tool P 2x.2" software for real-time visualization and user-friendly configuration.

4.2 Frontal view

Cable glands:



4.3 Status LED

The green LED "ON" informs about the operating status of the P 29.2.

LED status	Operating status
LED lights up continuously	Device in normal operation
LED flashes slowly (0.5 Hz)	<p>There is an operational problem:</p> <ul style="list-style-type: none">• Negative or positive pressure ($\pm 120\%$ of the measuring range)• Undervoltage supply• Short circuit at the voltage output (fault detection active at output voltages $> 1\text{ V}$)• Line break at the current output (fault detection active at output currents $> 0\text{ mA}$)
LED flashing (1 Hz) LED 800 ms ON and 200 ms OFF	Performing firmware update EEPROM Error
LED 20 ms ON and 980 ms OFF	No device firmware available Troubleshooting: Loading a device firmware, see chapter 6.9 Firmware update
LED flashes quickly (2 Hz)	Zeroing active

4.4 Configuration interface

The P 29.2 can be parameterized via the internal USB-C interface, and the actual values can be displayed. The prerequisite is a USB data connection cable.

The PC software can be found under <https://www.halstrup-walcher.de/en/downloads/>.

The minimum requirement for the trouble-free operation of the PC software is the installation of .NET Framework 4.8.

The P 29.2 is automatically detected when connected to the PC (from Windows 10 onwards) and the device settings are read. There is no need to install drivers.

4.5 Zeroing

Zeroing corrects for deviations caused by external influences such as temperature or location to ensure accurate readings. It can be triggered manually, externally, or time-controlled, whereby the current zero-point displacement is recorded and factored into the pressure measurement. During zeroing, the pressure measurement is inactive. The outputs are kept at the last measured value.

A positive edge at the External Zeroing input triggers the zeroing.

NOTICE

The best possible measurement accuracy is achieved at a room temperature of 23 °C.

4.5.1 Zeroing Interval

The distance between two zeros can be adjusted via the software. Cyclic zeroing can also be disabled, but this is not recommended.

4.5.2 External Zeroing

The devices also have an input to start a zeroing from the outside. With this it is possible to determine the time of zeroing depending on external regulations.

For connection assignments, see Chapter **5.2.3 Connection of input and output signals**.

NOTICE

If zeroing is invoked, it will be executed in any case. It is irrelevant whether the zero adjustment has been deactivated or the P 29.2 is in the menu.

4.6 Overpressure protection

The P 29.2 has an internal overpressure protection that protects the precision pressure load cell from destruction. (Overload range: 200 times [max. 100 kPa]). Applied overpressure/negative pressure (± 120 % of the measuring range) leads to zeroing of the load cell.

In the case of positive overpressure, the device outputs the maximum value of the set output stroke and in the case of negative overpressure the minimum value.

5 Electrical connection

The electrical connection is made via the cable glands on the device at the bottom and optionally for various signals via an M12 connector.

Trained specialists may only make the electrical connection.

5.1 Power consumption

The power consumption of the device is a maximum of 4 W with DC power supply or 8 VA with AC power supply.

For variants that carry the switching signal via the M12 connector, the switching capacity must be considered when designing the supply line and, if necessary, its fuse protection.

This can be up to 8 VA when using the semiconductor switch.

5.2 Preparing supply voltage through cable glands



WARNING!


Before opening, the device must be de-energized and secured!



WARNING!

The device may only be opened and electrically connected by qualified personnel.

For devices with cable glands, you can route the cables through the housing to the terminals for the supply voltage. Below is the illustration of the internal terminals.



The figure also shows optional components.

If the relay option has been ordered, the relays (X5) are equipped on the PCB; the component for the semiconductor switch (X4) is not present in this case, which corresponds to the correct construction.

If the relay option was not ordered, the terminal of the semiconductor circuit (X4) is equipped instead, while the relays (X5) are missing.

5.2.1 Selection of the cable cross-section


For X2 and X4: 0.2 mm² to 0.5 mm²

For X1 and X5: 0.2 mm² to 2.5 mm²

Both apply to both rigid and flexible cables.

The recommended stripping length is 10 mm.

5.2.2 Connection of the supply voltage




Designation	Description
+	Connect to DC supply "+" on the left side.
-	For DC supply "-" connect on the right side.

With alternating voltage, polarity does not matter.

The maximum values of the supply voltage depend on the variant and can be found in the data sheet.

5.2.3 Connection of input and output signals




Designation	Description
I_Out	Terminal through which the configured current signal is output.
GND	Ground
U_Out	Terminal through which the configured voltage signal is output.
Ext_Zeroing	Terminal, which can be used to start a zeroing of the device by means of a 24 V signal. (Attention: In variants with galvanic isolation, it must be noted that the ground of the supply has no connection to the ground of this terminal.)
Temp_Sens_1/2	Included for completeness only; not product-relevant.
GND	Ground
I_In	Included for completeness only; not product-relevant.
GND	Ground

5.2.4 Connection of the semiconductor switches (option)

The semiconductor switches may be loaded with a maximum of 24 V AC/DC and 0.325 A. The supply line must be designed according to the requirements.

Designation	Description
Sw_Out_2 COM	1st switching port of the second semiconductor switch
Sw_Out_2 NO	2nd switching terminal of the second semiconductor switch
Sw_Out_1 COM	1st switching terminal of the first semiconductor switch
Sw_Out_1 NO	2nd switching port of the first semiconductor switch




5.3 Supply voltage through connection plug

You can also optionally obtain the device with a connection plug.

Prerequisite:

For connection, please provide a cable with a suitable socket for the 4-pin, A-coded M12 plug.

Plan with the following pin assignment of the connector (top view from the outside):

	Option: supply, analogue output and ext. zeroing	Option: Power supply, analogue output and switching output
	1 Supply voltage	Supply voltage
	2 Output	Output
	3 Ground	Ground
	4 Ext. Zeroing	Switching

Supply voltage:

When supplied with DC voltage, connection for the positive supply. When using AC voltage, polarity does not have to be considered.

Ground:

When supplied with DC voltage, connection of the ground potential. When using AC voltage, polarity does not have to be considered.

Output signal:

Configured output signal (voltage/current) related to ground.

Ext. Zeroing (Option):

input to trigger a zeroing. This is triggered by applying 24 V DC in relation to the ground of the analogue plug.

Switching signal (option):

Normally open contact of the switching element, the second contact is connected to the supply voltage (pin 1) at the factory.

It must be ensured that the current flowing through the switching contact does not exceed 0.325 A. Failure to comply with this requirement may result in permanent damage to the device.

5.4 Starting conditions of the measuring system

To achieve the best possible accuracy, the device needs a **run-in time of about 30 minutes** after switching on until the temperatures of the electronics and sensor have levelled out. During the process, the device should remain completely locked.

The output signal can behave unstable during this time.

After the break-in period, the device should be zeroed to compensate for any offset drift that has occurred.

6 Functionality

Each P 29.2 unit can be customized by the user, in addition to the factory pre-configuration. There are **two options** available for this:


PC software "Start-Up Tool P 2x.2"

The device can be comprehensively configured and parameterized via the PC software.

In-device configuration (for devices with display)

If the device has an integrated display, the configuration can alternatively be carried out directly via the controls on the device.


6.1 User interface



The PC software is used to configure, parameterize and monitor the device. After starting the software and successfully connecting to the device, various functional areas are available to the user via the main menu.

Menu item	Description
File	Load existing device configurations onto the device and save current configurations to the local machine.
Language	Selecting the display language of the PC software. <ul style="list-style-type: none">• German• English• Italian• French
Parameterization	Carrying out the parameterization of the connected device.
Device	Configuration of device-specific settings as well as display settings. In addition, firmware updates can be carried out here.
Measured data	Display of the recorded measurement data in diagram form. The pressure measurement is displayed by default; other measurands must be configured beforehand.
Log	View a log to track historical data and events.

6.2 Login



If Access Protection (see **6.8 Device settings**) is enabled, a code (numeric, 0-999999) must be entered before accessing certain features.

A temporary deactivation of access protection is possible via a special sequence within the PC software "**Start-Up Tool P 2x.2**". The exact procedure for entering this sequence is documented in the software itself.

6.3 Alerts

Subsequent alerts can be displayed on the device.

NOTICE

The prerequisite for communication between P 29.2 and the PC software is a USB data connection cable.

Alerts	Potential cause	Possible solution
Scaling voltage output implausible	Upper and lower scaling values of the voltage output are at the same value	Properly scale voltage output under " Output "->" Voltage output "
Scaling current output implausible	Upper and lower scaling values of the current output are at the same value	Scale current output properly under " Output " ->" Current output "
Switching output 1/2 threshold value over measuring range	The threshold value of the switching output is set to a value that is not within the measuring range of the device	<ul style="list-style-type: none"> • Set threshold value within the measurement range • Order a device with a larger measuring range

Alerts	Potential cause	Possible solution
Switching output 1/2 hysteresis over measuring range	Hysteresis of the switching output is at a value that is not within the measuring range of the device	<ul style="list-style-type: none"> Set hysteresis within the measuring range Order a device with a larger measuring range
Dynamic pressure implausible	The value of the dynamic pressure is less than 1% of the measuring range of the device	<ul style="list-style-type: none"> Set dynamic pressure within the measuring range Order a device with a smaller measuring range
Value assigned to dynamic pressure is 0	The value of the dynamic pressure is set to 0	Enter a value for the dynamic pressure
Correction factor is 0	<ul style="list-style-type: none"> The correction factor has been set to 0 Dynamic pressure determination pressure >0 and calculated value =0 	<ul style="list-style-type: none"> Set the correction factor to >0 Configure dynamic pressure determination correctly
Switching output alarm sound exceeds 1000ms	Alarm tone of the switching outputs have a warning tone which totals >1000 ms	Set the alarm sound so that it results in a total of <=1000 ms .
Colour change switching output 1/2 configured, but switching output 1/2 deactivated	Colour switching under "Display" enabled but "Output" >"Switching output1/2" disabled	<ul style="list-style-type: none"> Activate switching output Disable colour switching for switching output
Undervoltage!	Supply voltage <17 V	Set the supply voltage to 24 V
Overvoltage!	Supply voltage >40 V	Set the supply voltage to 24 V
Overpressure/negative pressure detected!	>120 %/-120 % of the pressure measurement range is at the device	<ul style="list-style-type: none"> Relieve pressure Order a device with a larger measuring range
Fault current output	Power output is open	<ul style="list-style-type: none"> Connect the power output Disable power output
Voltage output error	Voltage output is shorted	<ul style="list-style-type: none"> Cancel short circuit Disable voltage output

6.4 Device Info




In the PC software, the device information is displayed from left to right in the following order:

Field	Description
Designation	Type designation of the device.
Variant number	Factory-assigned number to identify the specific device variant.
Serial number	Unique serial number of the device for traceability.
Version	Currently installed firmware version of the device.

6.5 Application

6.5.1 Mode

The P 29.2 supports various operating modes, which can be selected depending on the application. The operating mode is selected via the PC software or, in the case of devices with a display, directly on the device.



The following operating modes are available:


- Differential pressure
- Volume Flow
- Mass flow
- Flow Rate

NOTICE

The differential pressure measurement forms the basis for all other operating modes and can therefore always be parameterized. The conversion into volume flow, mass flow or flow velocity is carried out using a characteristic curve.

See chapter **6.5.3 Characteristic curve calculation**.

6.5.2 Pressure measurement




In this field, basic settings for differential pressure measurements and the zeroing interval can be made. The following options are available:

Function	Description
Pressure unit	Selection of the physical unit to represent the differential pressure. Available units: <ul style="list-style-type: none"> • Pascal (Pa) • Hectopascal (hPa) • Kilopascal (kPa) • Millibar (mbar) • Millimeters of water column (mmH₂O) • Millimeters of mercury (mmHg) • Pounds per Square Inch (psi) • Inches of water column (in H₂O) • Inches of mercury (inHg)
Span correction	Enables linear correction of the measurement span in the range of -5 % to +5 % .
Filter	Smoothing of the measured pressure values by means of an adjustable time constant. The values are filtered before output to the display and analog output. Setting range: 25 ms – 60000 ms
Zeroing Interval	Determination of the time interval for automatic zero point adjustment. The input is done in minutes .


6.5.3 Characteristic curve calculation

To calculate volume flow, mass flow or flow velocity based on the differential pressure measurement, the parameterization of a characteristic curve is required. This characteristic curve establishes the relationship between the measured differential pressure and the desired physical quantity. This characteristic curve can be determined using two different methods:

Method	Description
Correction factor	Scaling the calculated values by multiplying them by a user-defined correction factor. This method is suitable for applications with known flow characteristics. It can be determined in two ways and entered in the PC software
Point Calibration	Creation of an individual characteristic curve by entering up to 20, and at least 2 measuring points (pressure-value pairs). This method enables a more precise mapping of flow behaviour influenced by circumstances (e.g. canal routing).



The **correction factor** can be determined in advance with the help of the manufacturer's specifications / design of the system and then entered manually in the software.



Alternatively, the **correction factor** can be calculated directly in the software. For this purpose, the ratio between a measured differential pressure and the corresponding reference value (volume flow, mass flow rate or flow rate) is used:

Point calibration

6 ↑ ↓

[Pa]	[km/h]
0	0
20	10
40	30
60	90
80	480
100	1000

In addition to using a correction factor, the characteristic curve for calculating volume flow, mass flow or flow rate can also be determined by a multi-point calibration.

In **point calibration**, the characteristic curve is defined by entering several measuring points. Each point consists of a measured differential pressure value and the corresponding reference value (e.g. volume flow). The software interpolates between these points to enable precise mapping of unconventional flow characteristics.

Function	Description
Unit Volume Flow	Selection of the unit for the representation of the volume flow : <ul style="list-style-type: none"> • Cubic meter per second (m³/s) • Cubic meter per minute (m³/min) • Cubic meter per hour (m³/h) • Cubic foot per minute (cfm) • Cubic foot per hour (cfh)
Unit Mass Flow	Selection of the unit for the representation of the mass flow : <ul style="list-style-type: none"> • Kilograms per second (kg/s) • Kilograms per minute (kg/min) • Kilograms per hour (kg/h) • Pounds per second (lbs/s) • Pounds per minute (lbs/min) • Pounds per hour (lbs/h)
Unit Flow Rate	Selection of the unit for the representation of the flow rate : <ul style="list-style-type: none"> • Meters per second (m/s) • Miles per hour (mph) • Feet per second (fps) • Feet per minute (fpm) • Kilometers per hour (km/h)

Function	Description
Correction factor	Factor for calculating the flow quantity from the differential pressure. Can be entered manually or determined from known measured values. (Dynamic pressure determination)
Dynamic pressure determination	Calculation of the correction factor by entering a known differential pressure and the associated volume flow, mass flow or flow velocity.
Point Calibration	Creation of an individual characteristic curve by entering several measuring points (differential pressure and associated flow value). The software interpolates between the points for precise mapping of nonlinear flow conditions.
Creep Suppression	Setting for suppressing minuscule calculated values in the lower measuring range. This parameter specifies the value for creep suppression in percent. If the measured pressure falls below this value, the calculated variable (volume flow, mass flow, or flow velocity) is set to zero

6.6 Outputs

The device always has two analogue and two switching outputs. The outputs can be configured completely independently of each other.

For example, the voltage output and switching output 1 can simultaneously provide the differential pressure, while the current output and switching output 2 - depending on the configuration - can deliver either the volume flow or the temperature.

6.6.1 Analog Outputs

Interface <input checked="" type="checkbox"/> Voltage output [0/2 .. 10 V] <div style="border: 1px solid #ccc; padding: 5px; margin-top: 5px;"> Value differential pressure </div> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 5px;"> <input checked="" type="radio"/> 0 .. 10 V <input type="radio"/> 2 .. 10 V </div> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 5px;"> Lower Value (-1200 .. 1200) 0 [Pa] </div> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 5px;"> Upper Value (-1200 .. 1200) 1000 [Pa] </div>	<input checked="" type="checkbox"/> Current output [0/4 .. 20 mA] <div style="border: 1px solid #ccc; padding: 5px; margin-top: 5px;"> Value differential pressure </div> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 5px;"> <input type="radio"/> 0 .. 20 mA <input checked="" type="radio"/> 4 .. 20 mA </div> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 5px;"> Lower Value (-1200 .. 1200) 5 [Pa] </div> <div style="border: 1px solid #ccc; padding: 5px; margin-top: 5px;"> Upper Value (-1200 .. 1200) 100 [Pa] </div>
--	--

This settings area specifies the measured value to be output, along with its signal format and scaling parameters.

Function	Description
Value	Selection of the measured value to be output via the analogue output: <ul style="list-style-type: none">• Differential• Volume/mass flow rate or flow velocity• Temperature• Static pressure (optional)
Signal Type	Selection of the signal type for the analogue output: Voltage Signal Type: <ul style="list-style-type: none">• 0... 10 V• 2... 10 V Power Signal Type: <ul style="list-style-type: none">• 0... 20 mA• 4... 20 mA
Lower value	Reading that corresponds to the lower signal value (e.g. 0/2 V or 0/4 mA).
Upper value	Reading that corresponds to the upper signal value (e.g. 10 V or 20 mA).

NOTICE

In the event of a failure of the device, the outputs can assume the following states:

- In the event of an overpressure error in the differential pressure, the output is set to the maximum value of the output range.
- In the event of a negative pressure error of the differential pressure, the output is set to the minimum value of the output area.
- If the supply voltage is undervoltage (< approx. 18 V), the outputs are switched off (0 V or 0 mA).
- In case of other errors, the outputs are set to the following values:
 - when the voltage output is set to 0.. 10 V → 0 V
 - when the voltage output is set to 2.. 10 V → < 1.8 V
 - when the current output is set to 0.. 20 mA → 0 mA
 - when the current output is set to 4.. 20 mA → < 3.6 mA

6.6.2 Switching Outputs (Relays)

<input checked="" type="checkbox"/> Switching Output 1	<input checked="" type="checkbox"/> Switching Output 2
Value	
Differential pressure	
Switching threshold (-26.4 .. 26.4) 500 [kPa]	Switching threshold (-162.4808 .. 162.4808) 50 [kg/s]
Hysteresis (0 .. 26.4) 0 [kPa]	Hysteresis (0 .. 162.4808) 0 [kg/s]
Switch-on delay (0 .. 30000) 0 [ms]	Switch-on delay (0 .. 30000) 0 [ms]
Switch-off delay (0 .. 30000) 0 [ms]	Switch-off delay (0 .. 30000) 0 [ms]
<input type="checkbox"/> Warning Sound	<input checked="" type="checkbox"/> Warning Sound
<input type="checkbox"/> Inverted	<input checked="" type="checkbox"/> Inverted
<input type="checkbox"/> Filtered Value	<input checked="" type="checkbox"/> Filtered value

The device is equipped with two configurable switching outputs that can respond to specific measured values. In this section, the switching conditions and the behavior of the output signal can be configured.

NOTICE

If the supply voltage drops below 18 V, the switching contacts are deactivated.


Function	Description
Value	Selection of the measured value to which the switching output should react: <ul style="list-style-type: none"> • Differential • Volume/mass flow rate or flow rate • Temperature (optional) • Error/Alarm • Air consumption meter function
Switching Threshold	Limit value when the switching output is exceeded or undercut. Adjustment range: –120 % to +120 % of the nominal pressure measurement range or the calculated value.
Hysteresis	Determination of hysteresis to avoid switching flutter. Adjustable in the range of 0 % to 120 % of the nominal measuring range.
Switch-on delay	Time delay (in milliseconds) after which the switching output is activated once the threshold has been exceeded.
Switch-off delay	Time delay (in milliseconds) after which the relay switches back when the threshold value is undercut.
Warning Sound	Activation of an acoustic signal during switching operations. Adjustable pulse duration from 0 to 1000 ms (with a base duration for the period of 1000 ms). If both outputs are activated at the same time, the alarm duration adds up (max. 1000 ms).
Invert Signal	Inversion of the switching signal.
Apply filtered value	Enables the application of the previously set jump response time (see the section 6.5.2 Pressure measurement) to the switching output. This feature can be disabled.

NOTICE

If the switching output is set to "error output", the switching value and hysteresis settings are not available.

6.7 Display settings (optional)

For devices with a display, additional settings can be made within the device and the PC software



Function	Description
Display value	Select the value to be displayed on the display. Available options: <ul style="list-style-type: none"> • Differential • Volume Flow / Mass Flow / Flow Rate • Temperature • Air consumption meter function • Absolute pressure To display values other than differential pressure, the corresponding function must be configured beforehand and correctly parameterized.
Colour Switching	The LCD display shows the status of the switching outputs in colour. The function can be deactivated or activated for one or both outputs. <ul style="list-style-type: none"> • Green: Output inactive • Yellow: Output in hysteresis • Red: Output/outputs actively switched
Brightness	Adjustment of the backlight in the range of 0 to 15.
Contrast	Display contrast adjustment in the range of 0 to 32.
Backlight	Selecting the display lighting state: <ul style="list-style-type: none"> • Off • White • Blue

6.8 Device settings

In this section, basic settings for the device can be made.

Device Settings

Language

device protection

Auto Logout

Inactivity timeout (1..10080)
 [min]


overpressure protection

Key tone

Function	Description
Language	Selection of the device language. <ul style="list-style-type: none"> • German • English • French • Italian
Access protection	Enable access protection to prevent unauthorized changes.
Change code	Determination of an individual code (numeric, 0–999999) to ensure access protection.
Auto-Logout	Automatic logout of the user after a defined period of inactivity.
Inactivity Duration	Adjustable time span (in minutes) until automatic logout. The maximum period of inactivity is 7 days.
Overpressure protection	When the function is activated, automatic zeroing is carried out in the event of positive/negative pressure events ($\pm 120\%$ of the measuring range). This feature can be disabled.
Key tone	Activation of an acoustic signal when the controls are operated.
Factory	Restoration of factory-saved basic settings.

6.9 Firmware update

This section provides information on the firmware update.



Function	Description
Select update file	Select a locally stored firmware file to play on the device.
Firmware update	Starts the firmware update

NOTICE

During the update, the power supply must not be interrupted, as this can lead to a defective device.

Further information on the LED status during the update can be found in Chapter **4.3 Status LED**.

6.10 Display (option)

The display and the button menu are optional and not available on all variants of the P 29.2.

Four buttons are available for navigation and operation:



In the navigation of the device, a distinction is made between menu level and display mode. The function of the buttons varies depending on the active mode.

Key	Meaning (Display Mode)	Meaning (menu)
Left	Switch to menu mode (time lock 2 seconds)	Jump one menu level back/back to display mode Move cursor to the left
High	Start Zeroing	Increase value or scroll up
Down		Decrease the value or scroll down.
Right	Roll between Current Value -> Min Value -> Max Value	<ul style="list-style-type: none"> Jump one menu level in Move the cursor to the right Confirm



In *Display* the current measured value (or min. value or max. value) is displayed. The displayed value can be parameterized individually. See chapter **5.7 Display settings (optional)**
In this mode, the button on the right can be used to switch between measured value > min. value > max value. can be changed.

The top row of the display shows the current reading. The bottom line of the display on the right edge shows the unit of the display value.

If a zeroing of the device is currently active, its status is shown in the display.

In addition, the display shows the status of the switching outputs in the lower row on the left edge in the first two places and an indicator with reference to the present warning in the third place.

In the *Menu level* can be accessed the parameterization of the P 29.2, see **chapter 6.11 Menu Tree**. There are also notes on any available for warnings. From the Display mode can be accessed by pressing and holding the Left button "◀" to the menu level.

When Access Protection is activated, the menu is secured by an adjustable six-digit numerical code (numeric,0-999999).

Without entering the code, alerts and device information can be accessed, see chapter **6.3 Alerts**. All other functions are only accessible after a successful login.

6.11 Menu Tree

Main level	1. Sublevel	2. Sublevel	3. Sublevel	4. Sublevel
Login				
Alert	See 6.3 Alerts			
Device information	Designation			
	Variant number			
	Serial number			
	Version			
Application	Mode select	Pressure		
		Volume Flow		
		Mass Flow		
		Flow Rate		
	Param. method	Correction Factor		
		Point Calibration		
	Parameterization	Unit Volume Flow Unit Mass Flow Unit Flow Rate		
		Correction Factor settings	Manually	
			Enter dynamic pressure	Detect velocity pressure
				Enter velocity pressure

Main level	1. Sublevel	2. Sublevel	3. Sublevel	4. Sublevel
				V.Flow at vel. press. M.Flow at vel. press. Fl.Rate at vel. press.
		Creep suppression		
		Configure pressure measurement	Pressure unit	
			Set zeroing interval	
			Set filter constant	
Interface	Voltage output			
	Current output	Chosen measurement		
		Output type		
		Parameterize output		
	Switch output 1			
	Switch output 2	Chosen measurement		
		Set threshold		
		Invert output		
		Set hysteresis		
		Set switch-on delay		
		Set switch-off delay		
		Set sound length		
Display	Display value			
	Automatic colour change			
	Brightness			
	Contrast			
	Backlight			

Main level	1. Sublevel	2. Sublevel	3. Sublevel	4. Sublevel
Settings	Language			
	Activate password			
	Set password			
	Auto Logout			
	Overpressure protection			
	Span correction			
	Activate button sound			
	Reset min/max values			
	Factory reset			
Logout				

7 Specifications

For the technical data and the drawing, please refer to the current data sheet on the website:

<https://www.halstrup-walcher.de/en/downloads/>

Please contact us if you require further information.

8 Notes

halstrup-walcher GmbH
Stegener Straße 10-12
79199 Kirchzarten

Phone +49 7661 39 63-0
info@halstrup-walcher.de
www.halstrup-walcher.de